

| TOTAL KJELDAHL NITROGEN BY SEAL EPA-111-A REVISION 4 “TOTAL KJELDAHL NITROGEN-N (COPPER CATALYST) IN DRINKING, GROUND AND SURFACE WATERS, DOMESTIC AND INDUSTRIAL WASTES” REVISION DATE MAY 1, 2009 | | | | | PAGE 1 OF 2 |
|--|---------------------|---|---|-----|-------------|
| Facility Name: _____ VELAP ID: _____ | | | | | |
| Assessor Name: _____ Analyst Name: _____ Inspection Date: _____ | | | | | |
| Relevant Aspect of Standards | Method Reference | Y | N | N/A | Comments |
| <i>Records Examined:</i> SOP Number/ Revision/ Date _____ Analyst: _____ Sample ID: _____ Date of Sample Preparation: _____ Date of Analysis: _____ | | | | | |
| Were samples digested according to a procedure acceptable on 40CFR136? | 1.4 | | | | |
| Were samples preserved to pH < 2 with sulfuric acid and cooled ≤ 6°C and held for no longer than 28 days? | 40CFR136.3 Table II | | | | |
| Was the Stock Sodium Nitroferricyanide Dihydrate Solution prepared to a 30 g/L concentration? | 7.1 | | | | |
| Was the Digestion Reagent prepared with 134 g K ₂ SO ₄ /L, 7.3 g anhydrous Copper (II) Sulfate OR 11.4 g Copper (II) Sulfate Pentahydrate/L, and 134 mL concentrated H ₂ SO ₄ /L? | 7.1 | | | | |
| Was the Stock Sodium Hydroxide Solution prepared 100 g NaOH/L? | 7.1 | | | | |
| Was the Stock Potassium Tartrate Solution prepared 100 g/L | 7.1 | | | | |
| Was the Stock Buffer Solution prepared 67 g Na ₂ HPO ₄ OR 127 g Na ₂ HPO ₄ ·7H ₂ O, 10 g NaOH in 500 mL deionized water? | 7.1 | | | | |
| Was the Working Buffer Solution prepared 250 mL Stock Sodium Potassium Tartrate Solution, 100 mL Stock Buffer Solution, and (Table) Stock Sodium Hydroxide Solution in 500 mL DI Water? | 7.1 | | | | |
| Was the Stock Alkaline Sodium Salicylate Solution prepared 75 g anhydrous Sodium Salicylate and 10 g NaOH in 500 mL DI water? | 7.1 | | | | |
| Notes/Comments: | | | | | |

**TOTAL KJELDAHL NITROGEN BY
SEAL EPA-111-A REVISION 4****PAGE 2 OF 2****“TOTAL KJELDAHL NITROGEN-N (COPPER CATALYST) IN DRINKING, GROUND AND SURFACE WATERS,
DOMESTIC AND INDUSTRIAL WASTES”
REVISION DATE MAY 1, 2009**

| Relevant Aspect of Standards | Method Reference | Y | N | N/A | Comments |
|---|------------------|---|---|-----|----------|
| Was the anhydrous ammonium chloride (NH ₄ Cl) used to prepare standards dried at 105°C prior to use? | 7.2 | | | | |
| Was the Stock Standard Solution prepared with 3.819 g NH ₄ Cl per Liter DI water? | 7.2 | | | | |
| Were samples digested at 375°C to 385°C for 30 minutes? | 11.4 | | | | |
| Did the amount of DI Water added to samples to bring them back up to volume correspond to the recipe used for the Working Buffer? | 11.5 | | | | |

Notes/Comments: